



NO.	PART NUMBER	NAME	QTY.
1	ATP-75-10 X 1.25-F	BOLT BED	4
2	ATP-329	POST RETAINER	4
3		BED	1
4A	ATP-063-1	GUIDE POST 25'	4
4B	ATP-063-2	GUIDE POST 30'	4
5	ATP-375-16 X 4.50	BOLT BUSHING	40
6	ATP-1907	BUSHING	4
7		RAM	1
8	ATP-375-16-LN	NUT BUSHING	40
9		CROWN	1
10	ATP-182	CLAMP RING	4
11	ATP-875-9 X 4	BOLT POST	4
11A	ATP-875-9-LN	NUT POST	4
12	ATP-75-10-JN	NUT ROD	4
13	ATP-266	POSITIONER	4
14	ATP-75-10 X 12-R	POS. ROD	4
15	ATP-75-10-HN	NUT ROD	4
20	ATP-50-13 X 2.5	BOLT CLAMP	8
16	ATP-120	STUD SPRING	4
17	ATP-1-14-LN	NUT SPRING	4
18	ATP-1 ID	WASHER SPRING	4
19A	ATP-9-3248-2	SPRING RED	4
19B	ATP-9-3248-3	SPRING GOLD	4
23	ATP-171	UPSTOP	4
24	ATP-1-14-JN	NUT UPSTOP	4
21	ATP-1815	ADAPT. AIRTUBE	1
22A	ATP-189 (F-18)	AIRTUBE 18' O.D.	1
22B	ATP-190 (F-24)	AIRTUBE 24' O.D.	1
25	ATP-RR-200	ADAPT. RET.	1
26	ATP-2-224	O-RING	2
27	ATP-PG12000-01	PIPE PLUG	1
28	ATP-PG15000-01	PIPE PLUG	1
29	ATP-629	TANK	1
30	ATP-DC02000-01	DRAINCOCK	1
31	ATP-CB-1121-2	MOUNT SHOCK	3
32	ATP-J-2049-64	MOUNT WASHER	3
33	ATP-50-13 X 2	BOLT TANK	3
34	ATP-50 ID	WASHER TANK	3
35	ATP-053	POLY TIP	4
36	ATP-50-13 X 1	BOLT STOP	4
37	ATP-652	STOP HEAD	4
38	ATP-519-1	RAM STOP EXT.	4
39	ATP-519-2	RAM STOP EXT.	4
40	ATP-519-3	RAM STOP EXT.	4
41	ATP-519-4	RAM STOP EXT.	4
42A	ATP-50-13 X 1.5-SSC	SET SCREW STOP	16
42B	ATP-50-13 X 2-SSC	SET SCREW STOP	16
43	ATC-10032-R	AIR VALVE	1
44	ATP-1.50X1.25-HXBS-01	HEX BUSHING	1
45	ATP-N112002-01	PIPE NIPPLE	3
46	ATC-REG-125-01	REGULATOR	1
47	ATC-REG-GAU-01	GAUGE	1
48	ATC-FIL-125-01	FILTER	1
49	ATC-FIL-125-01	SHUT OFF	1

# PNEUMATIC PRESS 2.5" GUIDE POST



- TYPICAL MODELS:  
 ATP-118 ATP-8416  
 ATP-1615 R-4400  
 ATP-440 ATP-1640  
 ATP-1620 ATP-1645  
 ATP-451 ATP-1650  
 ATP-1625 ATP-1660  
 ATP-460 ATP-1840  
 ATP-1630  
 ATP-700  
 ATP-1635  
 ATP-650



# TANK ASSEMBLY

